
Welcome to

MANGO POWER!



DISPLAY

GENERAL DISPLAY SCREEN






The Power Move has a touchscreen display that shows all the necessary information needed to operate and control the Power Move and MANGO POWER Union. When the Power Move and Power Home are combined, the MANGO POWER Union combined page can be operated, and clicking on the Power Move/Power Home icons will only display the output and input power and cannot be controlled.



When the AC/DC/Backup/Smart Charge icons turn yellow from gray, it indicates that the specified function is now active.



The display shows the solar/grid charging power, as well as the load power.

AC/DC MODE



When the "AC" / "DC" icons are pressed and turn vellow from grav. the device can be connected to the socket / USB interface on the control panel, and wireless charging can be used.

SMART CHARGE



The Smart Charge feature can be used when fast charging with the grid or when charging simultaneously with solar panels or a generator.

SETTINGS



By clicking on the settings, you can adjust the charging rate of the MANGO POWER Union for different modes.

BACKUP MODE

Connect the load. The Backup mode defaults to 15A and 90% battery capacity (this can be modified in the settings).



When the "Backup" icon is lit in yellow, it indicates that the Backup mode has been activated. You can then view both the AC load power and the grid input, and the grid will continue to charge the battery to ensure the unit's power supply capabilities are maintained accordingly.

In the event of a power outage or overload, the MANGO POWER Union will automatically switch to battery power in less than 20 milliseconds to ensure immediate power supply.

GETTING STARTED

1. Turning on the device:

- Press and hold the Power Move and Power Home buttons for 1 second.
- The power button LED flashes and the Power Move touch screen turns on.

2. Charging your devices (such as phones, laptops, etc.) using the USB output port or DC socket:

You can use the USB port or wireless charging on the Power Move device, or connect your device to the DC power socket:

- Tap the "DC" icon on the touchscreen to enable DC power.
- Connect your device to the corresponding port.
- Allow your device to charge.

3. Using power-hungry devices (such as hairdryers, appliances, etc.):

- Select "AC" on the Power Move touchscreen and connect to an AC power source.
- Connect your device to the AC socket.
- Use your device as needed.

4. Connecting your MANGO POWER Union to your phone:

The MANGO POWER app allows you to remotely control your device, giving you peace of mind no matter where you are. Scan the QR code to download the app and get started.



MANGO POWER App

Before connecting the app, please turn on your MANGO POWER Union device and follow these steps:

- Open the MANGO POWER app, register and log in to your MANGO POWER account.
- Click on "Add Device", select the Power Move/Power Home icon, and enter the corre sponding SN code the SN code for the Power Move can be found by opening the Power Move panel or by tapping the "Mango Power" icon on the touchscreen. The SN code for the Power Home can be found on the bottom right of the base.
- Under the Internet Settings tab, enter your Wi-Fi network name and password to fully configure the device. Alternatively, you can also connect the device via Bluetooth.
- From then on, your MANGO POWER Union device can be fully controlled from the app.

5. Turning off the device:

- Press and hold the power button of the Power Move or Power Home for 1 second.
- The touchscreen and power button will turn off.

CONTACT US

If you have any questions, concerns, or queries, we would be delighted to hear from you!

Email us at service@mangopower.com, or simply call us at +1 (302) 219-4615 (Monday – Friday, 9 AM – 5 PM ET), or visit www.mangopower.com for more details.